

INSTALLATION OF THXX GPD PACKAGE

February 2018

1. General information

This GPD supports the Diebold Nixdorf Receipt Printers TH250, TH210-VI and TH230.

2. Disclaimer

There is no warranty for the program, to the extent permitted by applicable law. Except when otherwise stated in writing the copyright holder provides the program "as is" without warranty of any kind.

The entire risk as to the quality and performance of the program is with you. Should the program prove defective, you assume the cost of all necessary Servicing, repair or correction. There is no support provided for this package

3. Restrictions and comments

Important information for use of Diebold Nixdorf TH230 Receipt Printer:

After the TH230 GPD "TH230 Receipt Printer" is installed please perform the following procedures:



1. Open Device Manager and under "Other Devices" right click on DFUX Interface and select uninstall
This will remove the yellow bang on the TH230 Receipt in the Control Devices and Printers window.
2. Go to Devices and Printers in Control Panel
Right click on TH230 Receipt, select Printer Properties, Preferences, Advanced
Under Printer Features left click on "Printer Initialization",
Left click on the down arrow and select None.
This will prevent unwanted 2 characters („[Ç“) on the top of each receipt.

4. Installation Procedure


4.1. Log in as Windows administrator.

4.2. Unpack the file to a new directory. Preserve the directory structure of the package file.


4.3. Select 'Add Printer' from the Printers folder.




4.4. Choose a printer port.



4.5. Advance to the installation wizard screen that shows a list of Manufacturers and a list of Printers. Select the printer



4.6. Type a printer name



4.7. Adjust the printing properties in accordance to your preferences and printer parameters (e.g. paper adjustments).

